

Chapter 30 - Floor Pan Treatment, again (Video Clip 30)



1096. Vacuum or blow out the inside of the car and wipe down the floor pan and interior with a wet rag, then wipe dry with a dry rag.



1097. Begin painting Rust-Oleum Truck Bed material in the rear of the interior, as shown.



1098. Cover the entire floor pan with the truck bed material.



1099. The rear area shown, after painting one coat.



1100. View of the front area after painting one coat of the truck bed material.

(Work on this Section - 2 Hours)



1101. A couple of days for the material to completely dry, I painted a second coat of Rust-Oleum Truck Bed material.

<u>Number of Coats</u>		
<u>Rear Seat Area</u>	<u>Floor Pan Top</u>	<u>Floor Pan Bottom</u>
<ul style="list-style-type: none"> • 2 Coats POR15 • 2 Coats Truck Bed Material 	<ul style="list-style-type: none"> • 3 Coats POR15 • 2 Coats Truck Bed Material 	<ul style="list-style-type: none"> • 3 Coats POR15 • 1 Undercoat (Later)

That's All I know to do!

1102. The number of layers and type of material painted on various portion of my VW is shown at the left.



1103. A close up of finish floor pans and rear seat area.

Work on this section - 2 hours)

Work on this chapter - 4 hours

Total hours - 468